

APPLICATION INSTRUCTIONS

Easy Bind® (For General Repairs)
Easy Bind® and/or Easy Bind® Tyvek® (For Book Hinge Reinforcement)
Easy Bind® (For Reinserting a Page)

Easy Bind® (For General Repairs)




STEP 1 - Cut a strip of Easy Bind long enough to cover the tear and remove the Peel 'n Place® Centering Strip to expose 1/8" adhesive strip.

STEP 2 - Center the Easy Bind tape over the tear and press it into place.

STEP 3 - With a straight edge, such as a Ruler, push off the remaining liner and press the tape into place. Trim the excess tape.

Easy Bind® and/or Easy Bind® Tyvek® (For Book Hinge Reinforcement)




STEP 1 - Cut two strips of Easy Bind 1/4" shorter than the length of the book's spine.

STEP 2 - Remove the Peel 'n Place® liner from one strip.

STEP 3 - Wrap the Easy Bind around a Ruler, adhesive side out, and press the tape into the book hinge.

STEP 4 - Use the straight edge to push off the remaining liner, and press the tape into place. Repeat on opposite spine with second strip.

Easy Bind® (For Reinserting a Page)



STEP 1 - Cut two strips of Easy Bind 1/4" shorter than the length of the book's spine. Trim about 1/8" off of the outside edge of the page being inserted.

STEP 2 - Remove the liner from the right half of one tape strip. Press into place along inner edge of page. Remove Peel 'n Place®.

STEP 3 - Use a Ruler to anchor tape into hinge of book. Push remaining liner off and press tape into adjacent page. Reinforce back of page with second tape strip.